

Your Handle Type:

## Baldwin Images Entry



1

Loosen the set screw underneath the door handle.



2

Remove the door handle.



3

Pull out the thumb turn lock.



4

Slip the stem extension over the stem.



5

Install the extension and tighten the set screw.



6

Insert the thumb turn lock into the extension.



7

Install the door handle onto the extension and tighten the set screw.