

Your Handle Type:

Emtek Inactive



1

Loosen the set screw on the door handle. Unscrew the handle. Remove the nylon washer from the handle and save it for later.



4

Thread the 2-inch rod into the door handle. When you dry fit the handle into the extension, the rod should almost touch the mounting post.



2

Slip the brass sleeve over the threaded post in the escutcheon plate.



5

Place the nylon washer from the kit onto the door handle. Install the handle into the extension. **Make sure that all set screws line up.** Tighten the screws.



3

Place the nylon washer from **Step 1** onto the extension and dry fit it onto the mounting post. You may need to cut the bottom end of the extension shorter.