

Your Handle Type:

Hoppe Inactive



1

Use a 6-mm Allen wrench to remove the handle from the escutcheon plate.



2

Place the washer on the bolt.



3

Insert the bolt through the square hole on the back of the escutcheon plate.



4

Fit the extension over the bolt. Line up the square projection of the extension over the square hole in the escutcheon plate.



5

Seat the handle in the square hole of the extension.



6

Use a 3/4-inch or 19-mm socket to tighten the bolt.



7

Make sure that the door handle is perpendicular to the escutcheon plate.