

Your Handle Type:

Schlage Dexter Passage



1

Use a pin to release the door handle. Remove the handle.



2

Slide on the extension until the clip fits in the slot. Then hold the extension straight and tighten the set screw.



3

Slide on the door handle until it clicks in the slot.